DOCUMENT DETAILS V1	
Product:	XS Natural
Type:	QSG
Date Updated:	24-07-2025

TROUBLESHOOTING & TIPS

Mouse not connecting via Bluetooth?

- Ensure it's in Bluetooth mode (blue light)
- Hold the mode button until it blinks to enter pairing
- Retry from your device's Bluetooth settings

Mouse not responding?

- Turn OFF and ON using the switch
- Recharge the mouse using the Type-C cable
- Try another USB port (for 2.4GHz)

Cursor movement is lagging or inconsistent?

- Make sure the surface is clean and non-reflective
- Fully charge the mouse
- Avoid metal or glossy desks

Horizontal scroll not working smoothly?

- Clean the scroll wheel and check for obstructions
- Confirm app supports horizontal scrolling

Mouse disconnects frequently?

- . Ensure you're within 10 meters of the connected device
- Remove interference from other wireless devices (Wi-Fi routers, USB hubs)
- Re-pair the mouse if the issue persists

Battery draining too quickly?

- Avoid using the mouse while charging for optimal battery health
- Ensure the mouse is turned OFF when not in use for long periods

Device not switching properly?

- Wait 1-2 seconds after pressing the mode switch button
- Check for blinking light to confirm the selected mode

POWER SAVING MODE

The XS Series Natural Dual Scroll Rechargeable Bluetooth Mouse utilizes the energy-efficient 2.4GHz wireless radio frequency and Bluetooth. With its smart power-saving feature, the mouse automatically enters sleep mode if left idle for 10 minutes. Simply click a button to wake it up.

SPECIFICATIONS

Connection Type Bluetooth and USB 2.4GHz 3 (2x Bluetooth and 1x USB 2.4GHz) Devices 400-800-1600 (Default)-2400-3200 Buttons

: 800mAh Battery On/Off Switch : Yes Product Weight : 96g Product Dimensions : 106 x 73 x 68mm

WARRANTY STATEMENT


Amkette XS Series Natural Dual Scroll Rechargeable Bluetooth Mouse is backed by a 1 Year performance warranty against any manufacturing defect in material or workmanship from the date of original purchase. This warranty entitles the purchaser to get the product repaired or replaced at its discrete under the following conditions:


- The warranty applies to the original purchaser. Proof of original purchase is required.
- . The warranty does not cover the damage caused by misuse, abuse or improper storage. In no event shall Amkette be responsible for any direct, incidental, consequential or
- other damages of any kind.


Please contact our Technical Support Line and/or send the defective product, postage pre-paid, together with the proof of purchase to our Customer Care Service Center to avail warranty service. Return postage will be paid by us.

CUSTOMER CARE SERVICE CENTER

For Hassle Free Service Register Your Product www.amkette.com/register







Front Back