

DOCUMENT DETAILS V1	
Product:	Blaze 2 Wireless
Type:	User Manual
Date Updated:	30-12-2025
Paper Type	250 GSM Thick Card

Front

Back

Amkette House, C-64/4, Okhla Phase – II, New Delhi – 110020

+91 9312691448
(9:30 AM – 6:00 PM)

techsupport@amkette.in

For Hassle Free Service Register Your Product
www.amkette.com/register

128 x 77 x 40mm

84g

Yes (For Windows – Wired & 2.4G Only)

Windows, Mac OS, Android, iOS

Huano 20 Million (Left/Right), 1 Million (Others)

700fps

120 in/sec

25g

Wired – 1000Hz
2.4G – 500Hz
BT – 133Hz

125 / 250 / 500 / 1000Hz
200 – 12800 via Software

600 – 1200 – 2400 – 4800 – 7200 – 12800

8 Programmable Buttons

Wired + 2.4GHz Wireless + Bluetooth x 2

Specifications:

Warranty

Amkette EvoFox Blaze 2 Wireless Gaming Mouse is backed by a 1 year performance warranty against any manufacturing defects in material or workmanship from the date of original purchase. This warranty entitles the purchaser to get the product repaired or replaced at its discretion under the following conditions:
The warranty applies to the original purchaser, Proof of original purchase is required.
The warranty does not cover the damage caused by misuses, abuse or improper storage.
In no event shall Amkette be responsible for any direct, incidental, consequential or other damages of any kind.
Please contact our Technical Support Line and/or send the defective product, postage pre-paid, together with the proof of purchase to our Customer Care Service Center to avail warranty service. Return charges will be paid by us.


Customer Care

EVOFOX


BLAZE 2 WIRELESS

PROGRAMMABLE RGB GAMING MOUSE

QUICK START GUIDE



Know Your Mouse



1 Fire Button

2 Forward Button

3 Backward Button

4 Scroll Wheel

5 DPI Button

6 RGB Button

7 RGB Light/Indicator

8 Mode Switch Button

9 Device Switch Button

NOTE: All buttons on the Blaze 2 Wireless mouse are fully reprogrammable except mode and device switch button using the EvoFox software.

What's in the Box

Connection Guide

NOTE: Before proceeding with the connection process, please ensure that the mouse is charged using the provided Type-C cable.

Connecting via Bluetooth

FOR BT MODE
Slide Down

PAIRING
Blinks Fast

CONNECTING
Blaze2 M1 Search and Connect on your device

On switching modes, the RGB indicator will turn blue and blink slowly while attempting to reconnect to the last paired device.

If no device is detected within 7 seconds, the RGB indicator will blink rapidly to indicate pairing mode.

After successful pairing, the RGB indicator will remain solid blue for 2 seconds and then turn off.

To switch between BT1 and BT2, simply press the Device Switch button once.

NOTE: To force pair the mouse, long press the Device Switch button until the RGB indicator starts blinking rapidly

NOTE: In Bluetooth mode, the polling rate is limited to 133Hz

Connecting via USB 2.4GHz

NOTE: In case you need to re-pair the dongle with the mouse, long press the Device Switch button until the RGB indicator blinks green rapidly, then connect the receiver to the device.

NOTE: In 2.4GHz mode, the polling rate is default set to 500Hz and can be adjusted via software up to 1000Hz for smoother and more responsive performance.

Connecting via Cable

NOTE: If the mouse is connected via cable, it will automatically switch to wired mode, and other modes will be disabled.

NOTE: In Wired mode, the default polling rate is 1000Hz, and it can be adjusted via software as per user preference, ensuring maximum responsiveness and stability.

Pre-Programmed DPI Levels

600 - 1200 - 2400 - 4800 - 7200 - 12800

The mouse comes with pre-programmed DPI levels which can be customized through software.

Polling Rates

2.4GHz Mode: Default polling rate is 500Hz for power saving. It can be adjusted up to 1000Hz through the software.

Wired Mode: The polling rate is set to 1000Hz by default, though it can be adjusted through the software as per user preference.

Bluetooth Mode: Fixed at 133Hz for stable wireless performance.

Installation and Video Guide of the Software

Scan the QR and Watch Quick Tutorial Videos.

Download the Application by visiting
<https://www.amkette.com/qr/blaze-2-wireless-help>
The Software lets you customise all Buttons, create complex macros, and visually control backlighting