

DOCUMENT DETAILS V2	
Product:	Katana X2 Full Size
Type:	User Manual
Date Updated:	31-03-2026
Paper Type	250 GSM Thick Card

Katana X2 Full Size QSG

Front

Back

WARRANTY STATEMENT

Arnette Evofox Katana X2 Compact Full Size Mechanical Keyboard is backed by a 1 year performance warranty against any manufacturing defects in material or workmanship from the date of original purchase. This warranty entitles the purchaser to get the product repaired or replaced at its discretion under the following conditions:

The warranty applies to the original purchaser. Proof of original purchase is required.

The warranty does not cover the damage caused by misuse, abuse or improper storage.

In no event shall Arnette be responsible for any direct, incidental, consequential or other damages of any kind.

Please contact our Technical Support Line and/or send the defective product, postage pre-paid, together with the proof of purchase to our Customer Care Service Center to avail warranty service. Return postage will be paid by us.

CUSTOMER CARE CENTER

Arnette House, C-64/4, Okhla Phase - II, New Delhi - 110020

1800-11-9990 (Toll Free) (9:30 AM - 6:00 PM)

techsupport@arnette.in

www.arnette.com/register

SYSTEM REQUIREMENTS

Keyboard - Windows, MAC, Linux etc

Keyboard Type	Mechanical Keyboard (88%)
Switch Type	Linear Red Switch
Swappable Type	3 Pin Replacement
No. of Keys	97 Keys
Backlighting	Rainbow Lighting with 11 Effects
Dimensions & Weight	385 x 136 x 35.5 mm, 700g
Height	2 Level Adjustable
Cable Length	1.5m Braided Cable with USB Ring
Anti-Ghosting	All Keys Anti-Ghosting
Multifunction Volume Controller	For Adjusting Volume / Brightness



COMPACT FULL SIZE MECHANICAL KEYBOARD WITH RED SWITCHES







QUICK START GUIDE

HOW TO SWAP KEYS & SWITCHES

The Evofox Katana X2 supports 3-pin replaceable sockets, designed for occasional switch replacement in case of faults. Frequent swapping is not recommended, as it may affect durability.

- STEP-1** Use the Key Cap Puller to gently remove the desired Key Cap.
- STEP-2** Puller. Ensure to orient the Switch Puller so as to engage the clips on the Switch.
- STEP-3** Scan this QR code to access the video manual on Switch replacement.
- STEP-4** Place the removed Key Cap back on to the replaced Switch and press down firmly. The Legs are not being bent. Press down firmly, ensuring that the replacement Switch in the same orientation as the removed Switch.

BACKLIGHTING CONTROLS

ALL KEYS ANTI GHOSTING

KNOW YOUR KEYBOARD

Windows Lock Key, Backlighting Controls, Multimedia Buttons, Volume / Brightness Controller, LED Indicators

WHAT'S IN THE BOX

Mechanical Keyboard, Key Puller, 2x Switches, Docs

LONG LASTING RED SWITCHES

Key Life	50 Million
Activation Distance	2.00±0.6mm
Action Force	45±10gf
Total Travel Distance	4.00mm

MULTIFUNCTION VOLUME CONTROLLER

FOR VOLUME CONTROLS: Default Mode

Clockwise: Increase Volume
Anti-Clockwise: Decrease Volume
Single Press: Mute

FOR BRIGHTNESS LEVEL CONTROLS:

Long Press to Activate
Clockwise: Increase Brightness
Anti-Clockwise: Decrease Brightness
Single Press: Change Modes

KEYBOARD LED INDICATION

NUM LOCK - Num Key
CAPS LOCK - Caps Lock Key
WINDOWS LOCK - Fn+WIN Key