

WARRANTY STATEMENT

Amkette Optimus Pro 4-in-1 Rechargeable Wireless Keyboard is backed by a 1 Year performance warranty against any manufacturing defects in material or workmanship from the date of original purchase. This warranty entitles the purchaser to get the product repaired or replaced at its discrete under the following conditions:

- The warranty applies to the original purchaser. Proof of original purchase is required.
- The warranty does not cover the damage caused by misuse, abuse or improper storage.
- In no event shall Amkette be responsible for any direct, incidental, consequential or other damages of any kind.

Please contact our Customer Support Line and/or send the defective product, together with the proof of purchase to our Customer Care Service Center to avail warranty service. Return charges will be paid by us.

CUSTOMER CARE SERVICE CENTRE

Amkette House, C-64 / 4, Okhla Phase – II, New Delhi – 110020

1800-11-9090 (Toll Free)
(9:30 AM – 6:00 PM) Mon – Sat

+91 9312691448
(9:30 AM – 6:00 PM) Mon – Sat

techsupport@amkette.in

For Hassle Free Service Register your product online at www.amkette.com/register




AMKETTE
OPTIMUS PRO
4-in-1
Rechargeable Wireless Keyboard
QUICK START GUIDE

WHATS IN THE BOX



KNOW YOUR KEYBOARD



TROUBLESHOOTING

- **My keyboard does not work immediately after waking from sleep mode.**
Delayed response after sleep mode can occur due to Bluetooth reconnection time as it takes a few seconds to re-establish the connection.
- **Keyboard gets frequently disconnected from the device.**
Ensure you are within the effective Bluetooth range. Move closer to your device to establish a stable connection.
- **Some keys are not responding properly**
Check if any physical obstruction is causing any key to remain pressed down. Gently press every key to ensure that they are not stuck. Dirt can also obstruct the key responsiveness clean the keys regularly using a soft brush.

TECHNICAL SPECIFICATIONS

Technology	: 2.4 GHz Wireless and Bluetooth v5.0
No. of Devices	: 4 (3 Bluetooth and 1 USB)
Wireless Range	: up to 10 meters
Multimedia Keys	: 8
Membrane	: Silver Membrane
Battery	: 180 mAh
Weight	: 538g
Dimension	: 291x155x20mm

HOW TO USE ₹ SYMBOL

• **Change Language Settings**
Navigate to your computer's language settings and select **English (India)** as the keyboard language.

Ctrl + Alt + ₹ 4 24G

You may need to restart your device after changing your Keyboard's language settings.

MULTI OS ADAPTION

In Bluetooth, the keyboard automatically detects the OS, but you can switch manually if needed. Press **Fn + S** for macOS or **Fn + W** for Windows. Multimedia keys will adapt accordingly.

• **In Windows**

• **In Mac**

POWER SAVING MODE

After 10 minutes of inactivity the Keyboard will enter sleep mode. Press any key on the keyboard to wake it up. For Bluetooth connections the keyboard will reconnect to your device and can take 1-3 seconds.

Fn LOCK

This keyboard is designed to cater customer preferences. By default, Function Lock will be ON to access the Multimedia Functions and Device Switching. Turn OFF Function Lock to use standard F1 - F12 Functions.



SHORTCUT KEYS

BT1 F1	Bluetooth 1	F7	Emoticon
BT2 F2	Bluetooth 2	F8	Screenshot
BT3 F3	Bluetooth 3	F9	Play/Pause
24G F4	2.4G Mode	F10	Mute
F5	Copilot	F11	Vol -
F6	Home	F12	Vol +

GETTING STARTED

Before proceeding with the connection process, please ensure that the Keyboard is charged using the provided Type-C cable.

- Slide the ON/OFF switch towards ON.

CONNECTION GUIDE

With Bluetooth

You can connect with up to 3 devices via Bluetooth.

BT Device 1

SWITCHING (BT1 F1) Press

PAIRING (BT1 F1) Long Press

CONNECTING (Optimus P1) Search and Connect on your device

LED STATUS: BT (Blinks)

Repeat the process for BT Device 2 and 3.

If Fn Lock is OFF, use the Fn button to activate the device button.

With USB 2.4GHz

Take out the USB dongle from the USB receptacle on the back of keyboard and insert it into a USB port.

Press 2.4G to switch to the USB 2.4GHz mode.

LED STATUS: 24G (Blinks)

If Fn Lock is OFF, use the Fn button to activate the device button.

DEVICE SWITCHING

Press **BT1, BT2, BT3, 2.4G** to switch between the connected devices.

BT Device 1 (BT1 F1)

BT Device 2 (BT2 F2)

BT Device 3 (BT3 F3)

USB 2.4GHz (24G F4)

LED STATUS: BT (Blinks)

If Fn Lock is OFF, use the Fn button to activate the device button.