

WARRANTY STATEMENT

Amkette Optimus Pro Max 4-in-1 Rechargeable Wireless Keyboard is backed by a 1 Year performance warranty against any manufacturing defects in material or workmanship from the date of original purchase. This warranty entitles the purchaser to get the product repaired or replaced at its discrete under the following conditions:

- The warranty applies to the original purchaser. Proof of original purchase is required.
- The warranty does not cover the damage caused by misuse, abuse or improper storage.
- In no event shall Amkette be responsible for any direct, incidental, consequential or other damages of any kind.

Please contact our Customer Support Line and/or send the defective product, together with the proof of purchase to our Customer Care Service Center to avail warranty service. Return charges will be paid by us.

CUSTOMER CARE SERVICE CENTRE

Amkette House, C-64 / 4, Okhla Phase – II, New Delhi – 110020

1800-11-9090 (Toll Free)
(9:30 AM – 6:00 PM) Mon – Sat

+91 9312691448
(9:30 AM – 6:00 PM) Mon – Sat

techsupport@amkette.in

For Hassle Free Service Register your product online at www.amkette.com/register



AMKETTE

OPTIMUS PRO MAX

4-in-1


Rechargeable Wireless Keyboard

QUICK START GUIDE

WHATS IN THE BOX



KNOW YOUR KEYBOARD



- 1 ON/OFF Switch
- 2 Type C Charging Port
- 3 LED Indicators
- 4 Integrated Device Dock
- 5 Fn Lock
- 6 Multimedia Buttons
- 7 Device Switching Button
- 8 OS Switching Button
- 9 USB Receptacle

-2-

TROUBLESHOOTING

- **My wireless keyboard does not Work immediately after waking from sleep mode.**
Delayed response after sleep mode can occur due to Bluetooth reconnection time as it takes a few seconds to reestablish the connection.
- **Keyboard gets frequently disconnected from the device.**
Ensure you are within the effective Bluetooth range. Move closer to your device to establish a stable connection. And also ensure the batteries are inserted properly.
- **Some keys are not responding properly**
Check if any physical obstruction is causing any key to remain pressed down. Gently press every key to ensure that they are not stuck. Dirt can also obstruct the key responsiveness clean the keys regularly using a soft brush.

TECHNICAL SPECIFICATIONS

Technology	: 2.4 GHz Wireless and Bluetooth v5.0
No. of Devices	: 4 (3 Bluetooth and 1 USB)
Wireless Range	: Up to 10 meters
Multimedia Keys	: 12
Keyboard Type	: Silver Membrane
Battery	: 400 mAh
Weight	: 637g
Dimension	: 410 x 195 x 27mm

-7-

POWER SAVING MODE

In 2.4G mode, the keyboard enters sleep mode after 2 seconds of inactivity and deep sleep after 20 minutes, while in Bluetooth mode, it goes into deep sleep after 30 minutes.

Press any key on the keyboard to wake it up. For Bluetooth connections the keyboard will reconnect to your device and can take 1-3 seconds.

HOW TO USE ₹ SYMBOL

• Change Language Settings

Go to your computer's language settings and set keyboard's language to English (India).

You may need to restart your device after changing your Computers language settings.



WORKS WITH ALL YOUR DEVICES



-6-

Fn LOCK


By default, Fn Lock is OFF with access to default media functions. Press **Fn + Esc** to Toggle the Fn Lock.



SHORTCUT KEYS



To ensure optimal performance of the MM functions, please select the operating system you are using from the available set of keys above.



-3-

GETTING STARTED

Before proceeding with the connection process, please ensure that the Keyboard is charged using the provided Type-C cable.


- Slide the ON/OFF switch towards ON.

CONNECTION GUIDE

With Bluetooth

You can connect with up to 3 devices via Bluetooth.

BT Device 1




Repeat the process for BT Device 2 and 3.

-4-

With USB 2.4GHz

Take out the USB dongle from the USB receptacle on the back of keyboard and insert it into a USB port.




Press 2.4G Button to switch to the USB 2.4GHz mode.



DEVICE SWITCHING

Press **Dedicated Device Switching Buttons** to switch between the connected devices.



-5-

SIZE : 105X105MM_ BOOKLET STYLE PRINT