

WARRANTY STATEMENT

Amkette Wi-Key Max Wireless Keyboard and Mouse is backed by a 1 Year performance warranty against any manufacturing defects in material or workmanship from the date of original purchase. This warranty entitles the purchaser to get the product repaired or replaced at its discrete under the following conditions:

- The warranty applies to the original purchaser. Proof of original purchase is required.
- The warranty does not cover the damage caused by misuse, abuse or improper storage.
- In no event shall Amkette be responsible for any direct, incidental, consequential or other damages of any kind.

Please contact our Customer Support Line and/or send the defective product, together with the proof of purchase to our Customer Care Service Center to avail warranty service. Return charges will be paid by us.

CUSTOMER CARE SERVICE CENTRE

Amkette House, C-64 / 4, Okhla Phase – II, New Delhi – 110020

1800-11-9090 (Toll Free)
(9:30 AM - 6:00 PM) Mon – Sat

+91 9312691448
(9:30 AM - 6:00 PM) Mon – Sat

techsupport@amkette.in

For Hassle Free Service Register your product online at www.amkette.com/register



WI-KEY MAX


Wireless Keyboard and Mouse

QUICK START GUIDE

WHATS IN THE BOX



KNOW YOUR KEYBOARD



Keyboard

- 1 Fn Lock
- 2 Multimedia Shortcuts
- 3 LED Indicators
- 4 Device Switching Buttons
- 5 OS Mode Switch
- 6 Type C Charging Port
- 7 ON/OFF Switch
- 8 USB Receiver

Mouse

- 1 Scroll Wheel
- 2 DPI Button
- 3 Mode Switch
- 4 ON/OFF Switch
- 5 Type C Charging Port

-2-

TECHNICAL SPECIFICATIONS

KEYBOARD

Keyboard Type	: Wireless Keyboard
Connectivity	: 2xBT + 1x2.4GHz
Multimedia Keys	: 12
Battery	: 400mAH
Compatible Platforms	: Mac/Win/Linux/Android/iOS
Key Types	: Tear Drop Concave Keys
Dimensions	: 285 x 117 x 17 mm
Weight	: 471g

MOUSE

Connectivity	: 2xBT + 1x2.4GHz
Chipset	: Instant S201
DPI	: 800, 1200 (default), 1600, 3200
Battery	: 400mAH
Switch	: Huano (Left & Right Clicks)
Dimensions	: 110 x 60 x 32 mm
Weight	: 75g


-7-

HOW TO USE ₹ SYMBOL


Change Language Settings

Go to your computer's language settings and set keyboard's language to **English (India)**.

You may need to restart your device after changing your Computers language settings.



WORKS WITH ALL YOUR DEVICES



LED INDICATORS


LOW BATTERY



FN LOCK



OS MODE SWITCH



CAPS LOCK



-6-

Fn LOCK

By default, Fn Lock is OFF with access to default media functions.
Press **Fn + Esc** to Toggle the Fn Lock.



SHORTCUT KEYS & OS SWITCH



To ensure optimal performance of the MM functions, please select the operating system you are using from the available set of keys above.

- | | |
|-----------------|------------|
| Brightness down | Emoticon |
| Brightness Up | Play/Pause |
| Screenshot | Mute |
| Search | Vol - |
| Copilot | Vol + |
| Home | Lock |

-3-

CONNECTION GUIDE

Before proceeding with the connection process, please ensure that the Keyboard and Mouse is charged using the provided Type-C cable.

By default, Fn Lock is OFF with access to default media functions.
Press **Fn + Esc** in case Fn Lock is activated.

With USB 2.4GHz

Take out the USB dongle from the USB receptacle on the back of keyboard and insert it in to a USB port to connect both Keyboard & Mouse.



ON KEYBOARD: Press 2.4G mode Button to switch to the USB 2.4GHz mode.



ON MOUSE: Toggle through Switch Mode Button till 2.4G Led flashes.




-4-

With Bluetooth


You can connect with up to 2 devices via Bluetooth.

BT Device 1

ON KEYBOARD: Press Dedicated Device Switch Button to switch to the BT 1 mode.



ON MOUSE: Toggle through Switch Mode Button till BT 1 LED flashes.



Repeat the process for BT Device 2, for both Keyboard & Mouse.

-5-